


ASSEMBLY TIPS: 5 Important Points You NEED to Read

- -Prior to beginning assembly, please inspect and inventory the parts to make sure you have everything and that nothing was damaged during shipping. If damage has occurred, please take photos and go to lolldesigns.com/damage. Rest assured we'll get it taken care of straight away!
- Ņ To avoid scratching furniture, assemble on a clean, soft surface like a blanket, carpet, or the flattened cardboard box the furniture was shipped in.
- ω Start all bolts by hand to ensure proper alignment and to prevent cross threading. Then using the provided tool, tighten until you feel resistance. Do not overtighten.
- 4 still be installed without tools or excess force. Bolts should not be forced, but some components, particularly blocks, fit snug but can
- ŝ If parts are still not going together, please send us a photo of the part you are having trouble with.

BLOCK & BOLT INSTALLATION

as shown below. Insert bolts through countersunk hole side of blocks



"Loll Designs inspires people to appreciate the outdoors." Greg Benson - Founder

ASSEMBLY IN

RECYCLE THE PACKAGING

We've gone through great lengths to make as much of our packaging as possible recyclable. The cardboard box, paper wrap, filler and paper bags can all go in your recycling bin. The muslin hardware bags replaced plastic bags with the intention of reducing plastic and encouraging reuse. Loll Designs and Planet Earth thank you!

WE WANT YOU TO LOVE YOUR LOLL

For further lollygagging assistance, please reach out! For more info and visual aids, watch the assembly videos at www.lolldesigns.com/videos For product care & maintenance, visit www.lolldesigns.com/care-maintenance

- +1 877-740-3387
- sales@lolldesigns.com

Duluth, Minnesota 55807 5912 Waseca Street


















*** Please double check the bolt size required on each step. Use of wrong bolts will result in damage of product.***





















9


1‴

2x




*Caution:

Tighten bolts until parts are drawn tight together and stop. Do not overtighten bolts. ** Please use included 3/16[°] Allen Wrench for step 9.





In general, we recommend approximately a 2-ft minimum clearance in the back and front, and a foot on either side. As far as the seat height, we recommend it to be approximately 18" from the ground, but that can be a general approximation, due to each specific user.



LOLLYGAGGER SINGLE SWING SWING HANGING SUGGESTIONS

It is the responsibility of the end user to mount their swing securely.

DESIGNS



